

**AREA COVERAGE EST. FOR COATINGS FOR QUOTES**  
**[ONE PINT OR 300 grams per kit]**

<b>COATING</b>	<b>THICKNESS</b>	<b>FT<sup>2</sup>/KIT</b>	<b>CURE TIME</b>
<b>WHITE THERMAL CONTROL COATINGS</b>			
RM-400	4.0±1.5 mils	7-10 ft <sup>2</sup>	48 to 72 hours
AZ-400-LSW	3.0±1.0 mils	10-12 ft <sup>2</sup>	48 to 72 hours
AZ-93	5.0±1.5 mils	7-10 ft <sup>2</sup>	7 days
AZW/LA-II	7-13 mils	4-7 ft <sup>2</sup>	14 days
AZ-2000-IECW	4.0±1.0 mils	8-12 ft <sup>2</sup>	7 days
AZ-2100-IECW	5.0±1.0 mils	7-10 ft <sup>2</sup>	7 days
<b>BLACK SPACECRAFT COATINGS</b>			
MLS-85-SB <sup>1</sup>	3.0 +1.0,-1.5 mils	10-14 ft <sup>2</sup>	48 to 72 hours
AZ-1000-ECB	2.5±1.5 mils	10-12 ft <sup>2</sup>	7 days
ML-210-IB	2.5 +1.0, -1.5 mils	8-10 ft <sup>2</sup>	7 days
RM-550-IB	3.0 +1.0,-1.5 mils	10-12 ft <sup>2</sup>	7 days
TMD-560-IB	2.5 +1.0, -1.5 mils	8-10 ft <sup>2</sup>	7 days
<b>MARKER COATINGS</b>			
TMJ-20-SLB	2.0±0.5 mils	~10 ft <sup>2</sup>	24 hours
AMJ-450-LSG	3.0±1.0 mils	10-12 ft <sup>2</sup>	48 to 72 hours
AMJ-650-LSR	3.0±1.0 mils	10-12 ft <sup>2</sup>	48 to 72 hours
AMJ-750-LSBU	3.0±1.0 mils	10-12 ft <sup>2</sup>	48 to 72 hours
TMJ-850-LSY	3.0±1.0 mils	10-12 ft <sup>2</sup>	48 to 72 hours
TMJ-810-ICY	4.0±1.0 mils	13-16 ft <sup>2</sup>	7 days
AMJ-400-IG	3.0±1.0 mils	10-12 ft <sup>2</sup>	7 days
AMJ-600-IR	3.0±1.0 mils	10-12 ft <sup>2</sup>	7 days
AMJ-700-IBU	3.0±1.0 mils	10-12 ft <sup>2</sup>	7 days
AMJ-710-IBU	3.0±1.0 mils	10-12 ft <sup>2</sup>	7 days
TMS-800-IY	4.0±1.0 mils	13-16 ft <sup>2</sup>	7 days
<b>PRIMERS</b>			
MLP-100-AZ	0.75±0.25 mils	~17 ft <sup>2</sup>	7 days
MLP-300-AZ	0.75±0.25 mils	~17 ft <sup>2</sup>	7 days
<b>PROTECTIVE OVERCOATS</b>			
AZO-5000-PF	0.25±0.5 mils	4to 80 ft <sup>2</sup>	

<sup>1</sup> for specular coating, area coverage goes down to 8-12 ft<sup>2</sup>.